


Heat Call Not Recognized

3100/4100/5100 Series and 6100/7100/8100/9100 Series If Using Thermostat

Note: This flowchart is not applicable in applications with building load management systems.



Processor Control Board Test Point/Wire Locations

