

Item #1012011R – Switch Limit 320D 60T81X1762A-Repl

THIS PROCEDURE MUST BE PERFORMED BY A QUALIFIED TECHNICIAN

INSTALLATION

1. De-energize the system.
2. Remove the electrical panel cover and locate the defective core limit switch.
3. Disconnect the two black/yellow wires from the terminals on the defective core limit switch.
4. Remove the two mounting screws holding the core limit switch in place.
5. Remove the core limit switch and gasket.
6. Secure the new gasket and core limit switch in place using the mounting screws.
7. Connect the two black/yellow wires to the terminals on the core limit switch.
8. Install the electrical panel cover.
9. Energize the system and ensure proper operation.



WARNING

HAZARDOUS VOLTAGE:

Risk of electric shock. Can cause injury, or death. System may be connected to more than one branch circuit. Disconnect power to all circuits before servicing.

Core Limit Switches

