

STEFFES CORPORATION
DISCHARGE AIR SENSOR REPLACEMENT PROCEDURE
Models: 3100 Series

Item #1041536R (Sensor Discharge Air 3100/4100-Repl)

THIS PROCEDURE MUST BE PERFORMED BY A QUALIFIED ELECTRICIAN



WARNING

HAZARDOUS VOLTAGE: Risk of electric shock, injury, or death. System may be connected to more than one branch circuit. Disconnect power to all circuits before servicing. Equipment must be installed and serviced by a qualified technician.

1. De-energize the Comfort Plus system.
2. Remove the electrical panel cover and locate the discharge air sensor in the back of the electrical compartment (Figure 1).
3. Disconnect the wires from the discharge air sensor and remove the sensor.
4. Mount the new discharge air sensor assembly using the screws removed above.
5. Connect the wires as shown in Figure 2.
6. Reassemble the Comfort Plus system.
7. Energize the system and ensure proper operation.

Figure 1




Figure 2

