

Outdoor Temperature Sensor Reading Inaccurate

The outdoor temperature sensor should read within $\pm 10^{\circ}\text{F}/\pm 5.5^{\circ}\text{C}$. The outdoor temperature sensor must be placed in a location where it can accurately sense the outdoor temperature and will not be affected by direct sunlight, static heat, or other sources of heat and cold.

Temperature Sensor Resistance

